



Evo Curtain Heading Instruction Sheet

general advice for curtain-makers & decorators



Workroom equipment

Evo heading punch (left)

Evo button sliders (right)

Evo heading tape (100mm width)



Fullness

Allow approximately the same width as for traditional sewn pleat curtains, i.e. 2.5 times fullness. This will accommodate seam allowances, creepage, and enough space for return ends, which should be 16cm for curtains on a single bracket & 21cm for curtains on a double bracket.

Finished width

Bring the finished width of the curtains to the nearest 10cm (plus return ends). For example, for a single track with a width of 475cm, make the finished width of the 480cm, (plus 16cm for each return end).



Pleat measurement

Allow exactly 12cm for each and every reverse pleat loop and maintain a 10cm spacing between pleats. Please note, these measurements will ensure balance along the heading and smooth curtain operation.

Locating button sliders

Use the Evo heading punch to locate button sliders on each reverse pleat approximately 1cm from sewn line. When making curtains for the Evo track or Micro Rod, remove pin from heading punch to locate hole 5mm lower from the top of the heading.

